





IMPORTANT NOTICE:
HARDWARE PACKAGE IS ATTACHED ON THE
BOTTOM OF SEAT CUSHION.

MODEL: 16205 16206 16207 16215 16216 16217

(1)x1	(2)x1	(3)x1	(4)X1(L)X1(R)
			
BACK	SEAT	TU009-EXT	16206 / 16207 Arms
(5)x1	(6)x1	(7)x1	(8)X1
			
Gas Lift	Base	TU009	Mechanism
(9)X5	MODEL:B16206		
	Ax4  M8X20 Mechanism Screws Bx4  M6X22 Back Bar Screws Cx4  M6X22 Arm Screws Dx2  M6X25 Arm Screws		
Casters	MODEL:B16207		
Ax4  M8X20 Mechanism Screws Bx4  M6X22 Back Bar Screws	Cx4  M6X30 Arm Screws Dx2  M6X30 Arm Screws		



Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using.
 This chair is only intended for sitting. Any other use will void the warranty.

