



















IMPORTANT NOTICE:
HARDWARE PACKAGE IS ATTACHED
ON THE BOTTOM OF SEAT CUSHION.

① Backrest*1	② Seat Cushion*1	③ Right arm*1
		
③ Left arm*1	④ Mechanism*1	⑤ Headrest*1
		
⑥ Gas lift*1	⑦ Gas lift cover*1	⑧ Base*1
		
⑨ Casters*5		
		
⑩ (4*20)*2	⑪ (M6*30)*6	⑫ (M6*20)*2
		
⑬ (M8*20)*3	⑭ (M6*25)*2	⑮ Allen Key*1
		
⑯ Cross screwdriver*1		
		



Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using.
 This chair is only intended for sitting. Any other use will void the warranty.

