












IMPORTANT NOTICE:
HARDWARE PACKAGE IS ATTACHED
ON THE BOTTOM OF SEAT CUSHION.

MODEL : 6406

(1)x1	(2)x1	(3)x1 (L)x1 (R)
		
Back Cushion	Seat Cushion	Left-Arm-L Right-Arm-R
(4)x1	(5)x1	(6)x1
		
Gas Lift W/ Cover	Base	Mechanism
(7)x5	<div>(A)x4  M8 X 22 Mechanism Screws</div> <div>(B)x8  M6 X 30 Arm Screws</div> <div>(C)x1  ALLEN KEY</div>	
	Caster	



Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using.
This chair is only intended for sitting. Any other use will void the warranty.

