













IMPORTANT NOTICE:
HARDWARE PACKAGE IS ATTACHED
ON THE BOTTOM OF SEAT CUSHION.

MODEL : B6508

(1)x1	(2)x1	(3)x1 (L)x1 (R)
 Back Cushion	 Seat Cushion	 Left-Arm-L Right-Arm-R
(4)x1	(5)x1	(6)x1
 TU026 Gas Lift W/ Cover	 TU005 Nylon Base	 Mechanism
(7)x 5	<div><div>(A)x6   M6*28 ARM SCREW</div><div>(B)x4  M8*22 MECHANISM SCREW</div><div>(C)x4  M8*25 L-bar Screw</div></div>	
 TU015 Caster		



Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using.
This chair is only intended for sitting. Any other use will void the warranty.

