









MODEL :  B8401  B8801  B7201  B7206  
 B7301  B8106  B8501  B7901  B7306  
 B7906  B7701  B7706  B7641  B7741  
 B7501  B7506  B8101  B8506  B7601  
 B8306  B7806  B8811  B7801

(1)x1	(2)x1	(3)x1 (L)x1 (R)
		
(4)x 1	(5)x1	(6)x1
		
(7)x 5		
		

**Please unscrew all screws from cushion before assembly.**

- (A)\*8  **M6 \* 18** ARM SCREW
- (B)\*8  ARM CAP
- (C)\*4  **M8 \* 22** MECHANISM SCREW



**It is important to assemble all parts so that the directional "Arrows" point in the same direction. Make certain that all screws are FULLY tightened before using the chair. Each month, check all screws and tighten any that may have loosened.**

Warning: Do not stand on the seat for any purposes

