










**IMPORTANT NOTICE:  
HARDWARE PACKAGE IS ATTACHED  
ON THE BOTTOM OF SEAT CUSHION.**

MODEL: B9591 B9595

| (1)X1   | (2)X1   | (3)X1 (L)X1 (R)   |
|---|---|---|
|  |    |  |
| BACK  | SEAT  | RIGHT FRAME<br>& LEFT FRAME   |
| (4)X2   |   |   |
|   |   |   |
| Connecting bar  |   |   |
| <b>(A)x4</b>  |    | M6*36 SEAT SCREW  |
| <b>(B)x4</b>  |   | M6*25 BACK SCREW  |
| <b>(C)x1</b>  |  | ALLEN KEY   |



Insert and loosely tighten all screws.  
When assembly is completed, fully tighten  
all screws before using. This chair is only  
intended for sitting. Any other use will  
void the warranty.

