






BT-6177 - SOC - GG
PARTS

ASSEMBLY INSTRUCTION

(1)X1 	(8)X1 	① 	② 
(2)X1 	(9)X1 		
(3)X1 	(10)X1 	③ 	④ 
(4)X1 	(11)X1 		
(5)X1 	(12)X4 	⑤ 	⑥ 
(6)X1 	(13)X2 		
(7)X5 	(14)X4 		
	(15)X2 		
	(16)X1 		

BT-6181-FOOT PARTS

ASSEMBLY INSTRUCTION

