











BT-7821 PARTS

ASSEMBLY INSTRUCTION

(1)X1 	(9)X2  M8*55mm	① 	② 
(2)X1 	(10)X2  M8*25mm		
(3)X1(L)X1(R) 	(11)X4  M8*35mm	③ 	④ 
(4)X1 	(12)X4  6.5*18*1.5mm		
(5)X1 	(13)X4  8.5*22*2mm	⑤ 	⑥ 
(6)X1 	(14)X1  M5		
(7)X4  M6*20mm	(15)X1  M6		
(8)X4  M6*35mm	(16)X1 		