



Thank you for your purchase!

Gaming Chair

ASSEMBLY INSTRUCTIONS

Before You Begin:

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching during assembly.

Caution:

Tighten all components securely before use. Failure to do so may result in personal injury. DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Warning:

CHOKING HAZARD - Small Parts. Adult Assembly Required.

Injury may result from tipping furniture. You must install the Tipping Restraint Hardware with the unit to prevent the unit from tipping and causing any accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision.

This tipping restraint is not an earthquake restraint. If you wish to add the extra security of earthquake restraints, they must be purchased and installed separately.

Serious or fatal crushing injuries can occur from furniture tipping over. To prevent furniture from tipping over it must be permanently fixed to the wall. Fixing devices for the wall are not included since different wall materials require different types of fixing devices. Use fixing devices suitable for the walls in your home.


Failure to detach this restraint before moving furniture may result in injury or damage.

DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE


PARTS

1		1PC	9		1PC	D:		M8	20PCS
2		1PC	10		1PC	E:		M5*8	6PCS
3		1PC	11		1PC	F:		M6	1PC
4		1PC	12		1PC	G:			1PC
5		1PC	13		1PC				
6		1PC	A:		4PCS				
7		1PC	B:		16PCS				
8		5PCS	C:		20PCS				


STEP 1




STEP 2




STEP 3




STEP 4




STEP 5



STEP 6





Thank you for your purchase!
Gaming Table

ASSEMBLY INSTRUCTIONS

Before You Begin:

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching during assembly.

Caution:








Tighten all components securely before use. Failure to do so may result in personal injury. DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.


Warning:

CHOKING HAZARD - Small Parts. Adult Assembly Required.


DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE

PARTS



1.		1PC
2.		1PC
3.		1PC
4.		1PC
5.		2PC
6.		1PC
7.		1PC
8.		1PC
9.		2PC
10.	 Mouse pad	1PC

A		M6x12 20PCS
B		M6x30 8PCS
C		M6x60 4PCS
D		2PCS
E		4PCS
F		1PC
G		1PC
H		1PC



STEP 1



STEP 2





STEP 3





A X4

STEP 4






A X2





STEP 5






STEP 6





STEP 7



STEP 8



STEP 9



STEP 10

